
SERVICE MANUAL

CD STEREO RADIO CASSETTE RECORDER BASIC TAPE MECHANISM: TN-21ZVC-2000

BASIC CD MECHANISM: DA11T3C

• Replace this Service manual with "Revision Publishing" when it is issued.





ELECTRICAL MAIN PARTS LIST - 1/5

NOTE: The characters in the suffix column indicate the part usage.				
LHSC			A	
REF.NO PART	S NO. KANRI NO. D	ESCRIPTION	SUFFIX	
C 605 87-010 C 601 87-010 C 602 87-010 C 603 87-010 C 603 87-010 C 609 87-010 C 609 87-010 C 607 87-010 C 617 87-010 C 618 87-010 C 611 87-010 C 612 87-010 C 612 87-010 C 615 87-010 C 616 87-010 C 617 87-010 C 618 87-010 C 611 87-010 C 611 87-010 C 612 87-010 C 611 87-010 C 611 87-010 C 612 87-010 C 611 87-010 C 611 87-010 C 611 87-010 C 611 87-010 C 601 87-020 D 602 87-020 D 603 87-020 D 604 87-020 D 605 87-020 D 606 87-020 D 607 87-020 D 608 87-020 L 609 87-020 L 609 87-033 L 601 87-003 L 602 87-003 L 603 87-003 L 603 87-003 L 604 88-CD6 LED 606 88-CD6 LED 607 87-026 Q 606 87-026 Q 607 87-026 Q 608 87-026 Q 608 87-026 C 609 87-A91 S 601 87-A91 S 601 87-A91 S 601 87-A91 S 602 87-A91 S 601 87-A91 S 601 87-A91 S 602 87-A91 S 603 87-A91 S 603 87-A91 S 604 87-A91 S 607 87-A91 S 607 87-A91 S 607 87-A91 S 608 87-A91 S 608 87-A91 S 608 87-A91 S 609 87-A91 S 609 87-A91 S 609 87-A91 S 600 87-A91	-264-040	100-10 5L HIP 18 P S 27P-50 CH AP,S 39P CH S 56P-50 CH LECT 0.47-50V LECT 10-50V TOR,1-16 1-16 S 100P-50 SL 1000P-50 S 15P-50 CH LECT 10-50V 1-16 S 0.1-50 F 1-16 S 0.1-50 F 1-16 S 1.10MA) 1SS133 (110MA) 1SS133 (110MA	A. A	
	-465-010 DIODE, -465-010 DIODE,		A A	

ELECTRICAL MAIN PARTS LIST - 2/5

PR SP	901 901	87-A90-092-080 87-CD6-213-010	PROTECTOR, 2.5A 491 SPR-C, BATT (-)	A
SP SP	904 902	87-CD6-213-010 87-CD6-213-010	SPR-C,BATT (-) SPR-C,BATT (-)	A
SP C	903 211	87-CD6-213-010 87-010-805-080	SPR-C,BATT (-) CAP, S 1-16	A
CC	212	87-010-805-080	CAP, S 1-16	A
C	215 216	87-016-460-080 87-016-460-080	C-CAP,S 0.22-16 B C-CAP,S 0.22-16 B	A A
CCC	239 232	87-010-197-080 87-010-213-080	CAP, CHIP 0.01 DM	Α
Č	231	87-010-213-080	C-CAP,S 0.015-50 B	A
C	237 236	87-010-408-080 87-016-669-080	CAP, ELECT 47-50V C-CAP,S 0.1-25 K B	A A
C	235 234	87-016-669-080 87-A10-201-080	C-CAP,S 0.1-25 K B	Α
Č	233	87-A10-201-080	C-CAP, S0.33-16 KB	A
C	240 310	87-010-197-080 87-010-248-080	CAP, CHIP U.UI DM CAP, ELECT 220-10V	A
0000000000	483 484	87-012-156-080 87-012-156-080	C-CAP,S 220P-50 CH C-CAP,S 220P-50 CH	A
Ċ	819 820	87-010-426-080 87-010-426-080	C-CAP, S 0.012-25 B	A
D	310	87-020-465-080	DIODE, 1SS133 (110MA)	A
IC C	203 263	87-A21-520-040 87-010-178-080	C-IC,M61509FP CHIP CAP 1000P	A
C	264 262	87-010-178-080 87-010-402-080	CHIP CAP 1000P	Α
C	261	87-010-402-080	CAP, ELECT 2.2-50V	A
C	266 267	87-010-545-080 87-010-545-080	CAP, ELECT 0.22-50V CAP, ELECT 0.22-50V	A A
00000000	272 271	87-010-237-080 87-010-237-080	CAP, ELECT 1000-16V	A
Ĉ C	279 278	87-010-263-080 87-010-263-080	CAP, ELECT 100-10V	A
С	277	87-010-404-080	CAP, ELECT 100-10V CAP, ELECT 4.7-50V	A
CN IC	202 202	8A-CH4-689-010 87-A21-090-010	CONN, 3P V 2.5 IC, LA4600	A
С	308 307	87-010-221-080 87-010-401-080	CAP, ELECT 470-10V	Α
Č	306	87-010-404-080	CAP, ELECT 4.7-50V	Ā
00000	301 311	87-016-495-000 87-010-374-080	CAP, E 3300-25 M SMG CAP, ELECT 47-10V	A
C C	312 325	87-010-385-080 87-010-405-080	CAP, ELECT 220-25V CAP, ELECT 10-50V	A
ČN D	301 306	8A-CH4-689-010 87-070-345-080	CONN, 3P V 2.5	A
D	305	87-070-345-080	SPR-C, BATT (-) CAP, S 1-16 CAP, S 1-16 C-CAP, S 0.22-16 B C-CAP, S 0.22-16 B C-CAP, S 0.015-50 B CAP, CHIP 0.01 DM C-CAP, S 0.015-50 B C-CAP, S 0.1-25 K B C-CAP, S 0.33-16 KB C-CAP, S 0.33-16 KB C-CAP, S 0.33-16 KB C-CAP, S 0.012-25 B C-CAP, S 220P-50 CH C-CAP, S 220P-50 CH C-CAP, S 0.012-25 B DIODE, 1SS133 (110MA) C-IC, M61509FP CHIP CAP 1000P CHIP CAP 1000P CAP, ELECT 2.2-50V CAP, ELECT 0.22-50V CAP, ELECT 10.22-50V CAP, ELECT 10.22-50V CAP, ELECT 1000-16V CAP, ELECT 1000-16V CAP, ELECT 1000-16V CAP, ELECT 1000-10V CAP, ELECT 100-10V CAP, ELECT 100-10V CAP, ELECT 100-10V CAP, ELECT 1-50V CAP, ELECT	Ā
D D	303 304	87-070-345-080 87-A40-648-080	ZENER, MTZJ8.2A	A
D O	311 303	87-027-702-080 87-026-291-080	DIODE,ZENER HZ6C2L (200MA) TR,DTC124XS	A A
Q Q Q	305 302	87-026-462-080 87-026-463-080	TR,2SC1740 S(RS 0.3W) TR,2SA933S (0.3W)	A
Q	301	89-112-965-080	TR, 2SA1296 (0.75W)	A
Q	304 310	89-213-702-080 89-318-154-080	TR,2SB1370E TR,2SC1815 (0.4W)	A
C C	30 801	87-010-260-080 87-010-248-080	CAP, ELECT 47-25V CAP, ELECT 220-10V	A A
Č	807 809	87-010-405-080 87-010-405-080	CAP, ELECT 10-50V CAP, ELECT 10-50V	A
Č	808	87-010-405-080	CAP, ELECT 10-50V	A
C	805 806	87-012-365-080 87-012-365-080	C-CÁP,S 0.027-25VBK C-CAP,S 0.027-25VBK	A A
C C	812 811	87-010-178-080 87-010-178-080	CHIP CAP 1000P CHIP CAP 1000P	A A
Ċ	816 817	87-010-180-080 87-010-180-080	C-CER 1500P C-CER 1500P	A
Č	810	87-010-405-080	CAP, ELECT 10-50V	A
C	823 829	87-010-178-080 87-010-178-080	CHIP CAP 1000P CHIP CAP 1000P	A A
C C	824 821	87-010-178-080 87-010-401-080	CHIP CAP 1000P CAP, ELECT 1-50V	A A
Č	822	87-010-401-080	CAP, ELECT 1-50V	A
Ç	830 831	87-010-178-080 87-010-198-080	CHIP CAP 1000P CAP, CHIP 0.022	A A
C	834 835	87-010-248-080 87-010-322-080	CAP, ELECT 220-10V C-CAP,S 100P-50 CH	A A
000000000000000000000000000000000000000	836 833	87-010-322-080 87-018-195-080	C-CAP,S 100P-50 CH CAP, CER 1200P-16V	A A
Č	845 843	87-010-178-080 87-010-197-080	CHIP CAP 1000P CAP, CHIP 0.01 DM	A
C	846	87-010-263-080	CAP, ELECT 100-10V	A A
C C C	844 852	87-018-124-080 87-010-178-080	CAP, CER 270P-50V CHIP CAP 1000P	A A
C C	851 853	87-010-186-080 87-A11-145-080	CAP, CHIP 4700P CAP, TC U 0.01-50 Z F	A
_	555	1. 1111 110 000	,	

ELECTRICAL MAIN PARTS LIST - 3/5

CN	801	87-A60-110-010	CONN,4P V S2M-4W	A
ČΝ	802	8A-CH4-687-010	CONN, 4P V 2.5	Ā
D	308 309	87-017-978-080 87-070-345-080	DIODE, 1N4003	A
D D	809	87-020-465-080	DIODE,IN4148 DIODE,1SS133 (110MA)	A A
D	808	87-070-345-080	DIODE, IN4148	A
D	807	87-070-345-080	DIODE, IN4148	Ā
D	810	87-020-465-080	DIODE, 1SS133 (110MA)	A
ΙC	801	87-A21-431-010	IC, BA4560N	A
L	801 801	87-007-342-010 89-318-154-080	COIL,OSC 85K BIAS TR,2SC1815 (0.4W)	A
Q Q R	810	87-026-464-080	TR, DTC114TS (0.3W)	A
Ř	840	87-029-124-010	RES, FUSE 2.2-1/4	A
SW	801	8Z-CD9-609-010	SW,SL 1-6-2 PS62D01	A
C	321	87-010-197-080	CAP, CHIP 0.01 DM	A
C CN	322 201	87-010-263-080 87-099-018-010	CAP, ELECT 100-10V CONN,16P	A
CN	302	8A-CD9-629-010	CONN, 101 CONN ASSY, 6P MA-TU	A
Ď	32	87-027-607-080	ZENER, HZ7B3L	A
D	323	87-070-345-080	DIODE, IN4148	A
Q	321	89-318-154-080	TR, 2SC1815 (0.4W)	A
Q	841 407	87-026-291-080 87-010-178-080	TR,DTC124XS CHIP CAP 1000P	A
C	407	87-010-170-080	CAP, CHIP 0.01 DM	A
Č	405	87-010-197-080	CAP, CHIP 0.01 DM	A
С	408	87-010-198-080	CAP, CHIP 0.022	A
C	404	87-010-248-080	CAP, ELECT 220-10V	A
C	409 403	87-010-248-080 87-010-263-080	CAP, ELECT 220-10V CAP, ELECT 100-10V	A A
Č	406	87-010-203-000	CAP, ELECT 47-10V	A
Č	401	87-010-403-080	CAP, ELECT 3.3-50V	A
С	418	87-010-213-080	C-CAP,S 0.015-50 B	A
C	410	87-010-263-080	CAP, ÉLECT 100-10V	A
C	412 414	87-010-401-080 87-010-405-080	CAP, ELECT 1-50V CAP, ELECT 10-50V	A
Č	416	87-010-545-080	07 D T T C C C C C C C C C C C C C C C C C	
Č	417	87-012-157-080	C-CAP, S 330P-50 CH	A
Ç	413	87-016-369-080	C-CAP,S 0.033-25 B K	Ā
С	411	87-A11-177-080	C-CAP, S 0.15-16 K B	A
C	419 425	87-A11-608-080 87-010-176-080	C-CAP,S 0.33-25 K B	A
Č	422	87-010-184-080	CHIP CAPACITOR 3300P(K)	A
Č	429	87-010-186-080	CAP, CHIP 4700P	A
000000000000000000000000000000000000000	428	87-010-197-080	CAP, ELECT 0.22-50V C-CAP,S 330P-50 CH C-CAP,S 0.033-25 B K C-CAP,S 0.15-16 K B C-CAP,S 0.33-25 K B C-CAP,S 680P-50 SL CHIP CAPACITOR 3300P(K) CAP,CHIP 4700P CAP,CHIP 0.01 DM C-CAP,S 0.047-25 B C-CAP,S 0.033-25 B K C-CAP,S 0.22-16 B C-CAP,S 0.15-16 K B C-CAP,S 0.33-25 K B CHIP CAP 1000P	Ā
C	423	87-010-992-080	C-CAP, S 0.047-25 B	A
C	420 424	87-016-369-080 87-016-460-080	C-CAP,S 0.033-25 B K	A A
Č	421	87-A11-177-080	C-CAP.S 0.15-16 K B	A
Č	426	87-A11-608-080	C-CAP, S 0.33-25 K B	A
C	439	87-010-178-080	CHIP CAP 1000P	A
C	434	87-010-184-080	CHIP CAPACITOR 3300P(K)	A
C	435 432	87-010-197-080 87-010-374-080	CAP, CHIP 0.01 DM CAP, ELECT 47-10V	A
	436	87-010-374-080	CAP, ELECT 47-10V	A
Č	433	87-010-401-080	CAP, ELECT 1-50V	A
Ç	437	87-010-404-080	CAP, ELECT 4.7-50V	<u>A</u>
C	431	87-010-545-080 87-012-156-080	CAP, ELECT 0.22-50V	A
Č	430 438	87-012-136-060	C-CAP,S 220P-50 CH C-CAP,S 0.1-25 K B	A A
Č	441	87-010-197-080	CAP, CHIP 0.01 DM	A
C	442	87-010-313-080	CAP, CHIP 18P	A
C	448	87-010-315-080	C-CAP, S 27P-50 CH	A
C	445 447	87-012-368-080 87-012-368-080	C-CAP,S 0.1-50 F C-CAP,S 0.1-50 F	A
C	447	87-012-368-080	C-CAP,S 0.1-50 F	A A
č	455	87-010-247-080	CAP, ELECT 100-50V	A
С	459	87-010-263-080	CAP, ELECT 100-10V	A
C	458	87-010-312-080	C-CAP, S 15P-50 CH	A
C	457 450	87-010-312-080 87-012-140-080	C-CAP,S 15P-50 CH CAP 470P	A
Č	451	87-012-140-080	C-CAP, S 220P-50 CH	A
Č	463	87-010-197-080	CAP, CHIP 0.01 DM	A
С	461	87-010-197-080	CAP, CHIP 0.01 DM	A
C	462	87-010-248-080	CAP, ELECT 220-10V	A
\mathcal{C}	467 465	87-010-263-080 87-010-404-080	CAP, ELECT 100-10V CAP, ELECT 4.7-50V	A
Č	469	87-010-404-080	C-CAP,S 150P-50 CH	A
Č	466	87-012-368-080	C-CAP,S 0.1-50 F	A
Č	460	87-015-819-080	CAPACITOR, 0.01	A
C	475	87-010-197-080 87-010-197-080	CAP, CHIP 0.01 DM	A
\mathcal{C}	477 479	87-010-197-080	CAP, CHIP 0.01 DM CAP, CHIP 0.01 DM	A
č	476	87-010-236-080	CAP, E 1000-10 SME	A
, , , , , , , , , , , , , , , , , , ,	478	87-010-263-080	CAP, ELECT 100-10V	A
C	470	87-010-544-080	CAP, ELECT 0.1-50V	A
Ċ	473 474	87-015-785-080 87-015-785-080	CHIP CAPACITOR, 0.1FZ-25Z CHIP CAPACITOR, 0.1FZ-25Z	A A
0	1/1	0, 010 700 000	0.11 0.11.01.10.1, 0.11.0 200	

ELECTRICAL MAIN PARTS LIST - 4/5

C 472	87-015-785-080	CHIP CAPACITOR, 0.1FZ-25Z	A
C 471	87-015-785-080	CHIP CAPACITOR, 0.1FZ-25Z	A
C 480	87-010-221-080	CAP, ELECT 470-10V	A
C 482	87-010-405-080	CAP, ELECT 10-50V	A
C 481	87-010-405-080	CAP, ELECT 10-50V	
C 489	87-012-368-080	C-CAP, S 0.1-50 F	A
C 494	87-010-197-080	CAP, CHIP 0.01 DM	A
C 490	87-012-368-080	C-CAP, S 0.1-50 F	A
C 506	87-010-322-080	C-CAP,S 100P-50 CH	A
C 505	87-010-322-080	C-CAP,S 100P-50 CH	A
C 502	87-010-322-080	C-CAP,S 100P-50 CH	A
C 503	87-010-322-080	C-CAP,S 100P-50 CH	A
C 504	87-010-322-080	C-CAP,S 100P-50 CH	A
C 501	87-012-368-080	C-CAP,S 0.1-50 F	A
C 510	87-016-669-080	C-CAP,S 0.1-25 K B	A
CN 205	87-A60-109-010	CONN,2P V S2M-2W	A
CN 403	87-099-201-010	CONN,8P 6216 H	A
CN 401	87-A60-424-010	CONN,16P V TOC-B	A
CNA 402	8A-CD9-625-010	CONN ASSY,6P CD-ME	A
D 401	87-070-345-080	DIODE, IN4148	A
D 402	87-070-345-080	DIODE, IN4148	A
D 403	87-070-345-080	DIODE, IN4148	A
IC 401	87-A20-446-010	C-IC, LA9241ML	A
IC 402	87-A20-459-010	C-IC, LC78622ED	A
IC 404 L 401	87-A21-093-010 87-003-102-080 87-003-152-080	IC,LA6541D COIL, 10UH	A A
L 404 Q 408 Q 403 Q 407 Q 406 Q 401 Q 402 SFR 430	87-026-295-080 87-026-295-080	COIL, 100UH TR,DTC144TK TR,DTC144TK	A A A
Q 407	87-026-295-080	TR,DTC144TK TR,DTC144TK TR,2SA933RS	A
Q 406	87-026-295-080		A
O 401	89-109-332-380		A
Q 402	89-113-187-080	TR,2SA1318TU	A
SFR 430	87-024-437-080	SFR100K,RH063EC	A
C 491 C 492	8Z-CD5-633-010 87-010-197-080 87-010-221-080	VIB, CER16.93MHZ FCR16.93M2 CAP, CHIP 0.01 DM CAP, ELECT 470-10V	A A A
D 491	87-070-345-080	DIODE, IN4148	A
	87-070-345-080	DIODE, IN4148	A
	87-026-291-080	TR, DTC124XS	A
Q 491 C 9	89-112-965-080 87-010-154-080 87-010-197-080	TR,2SA1296 (0.75W) CAP CHIP 10P	A A
C 8 C 1 C 3 C 2	87-010-314-080 87-010-317-080	CAP, CHIP 0.01 DM C-CAP,S 22P-50V C-CAP,S 39P-50 CH	A A A
C 2	87-010-318-080	C-CAP, S 47P-50 CH	A
C 6	87-010-378-080	CAP, ELECT 10-16V	A
C 7	87-018-208-080	CAP 0.047-50F	A
Q 492 491 8 1 8 2 6 7 7 13 11 6 16 15	87-010-148-080 87-010-154-080 87-010-178-080	CAP, CHIP S 75P SL CAP CHIP 10P CHIP CAP 1000P	A A A
	87-010-196-080 87-010-197-080	CHIP CAPACITOR, 0.1-25 CAP, CHIP 0.01 DM	Ä
C 10	87-010-197-080	CAP, CHIP 0.01 DM	A
C 12	87-010-314-080	C-CAP,S 22P-50V	A
C 14	87-012-141-080	CHIP-CAPACITOR,0.22-16F	A
C 17 C 25 C 22	87-016-669-080 87-010-197-080 87-010-197-080	C-CAP,S 0.1-25 K B CAP, CHIP 0.01 DM	A
C 24 C 20	87-010-197-080 87-010-400-080	CAP, CHIP 0.01 DM CAP, ELECT 0.47-50V	A A A
C 21	87-010-403-080	CAP, ELECT 3.3-50V	A
C 29	87-010-992-080	C-CAP,S 0.047-25 B	A
C 28	87-010-992-080	C-CAP,S 0.047-25 B	A
CC 12 14 17 22 22 22 20 21 29 22 26 27 22 23 33 33 31 37	87-012-141-080 87-012-141-080 87-010-197-080	CHIP-CAPACITOR, 0.22-16F CHIP-CAPACITOR, 0.22-16F CAP, CHIP 0.01 DM	A A A
C 34	87-010-197-080	CAP, CHIP 0.01 DM	A
C 33	87-010-197-080	CAP, CHIP 0.01 DM	
C 30	87-010-248-080	CAP, ELECT 220-10V	A
C 31	87-010-379-080	CAP, ELECT 22-16V	A
C 37	87-012-155-080	C-CAP 180P-50CH	A
CF 1	87-008-261-010	FILTER, SFE10.7MA5-A	A
CF 2	87-008-261-010	FILTER, SFE10.7MA5-A	A
CF 1	87-A90-128-010	FLTR,AM IF CFAL-455	A
D 4 D 1	87-020-465-080 87-020-465-080 87-020-465-080	DIODE, 1SS133 (110MA) DIODE, 1SS133 (110MA) DIODE, 1SS133 (110MA)	A
D 3 IC 1	87-A40-128-080 87-A20-955-010	C-VARI-CAP, HVU202A IC, LA1828	A A A
L 9	87-A50-334-010	COÎL,FM DET (TOKO)	A
L 8	87-A50-335-010	COIL,FM IFT (TOKO)	A
L 7	87-A50-336-010	COIL,AM IFT (TOKO)	A
L 6	87-A50-337-010	COIL, AM OSC (TOKO)	A
L 5	87-A50-342-010	COIL, FM OSC D	A
L 4	87-A50-345-010	COIL, FM RF EX	A
L 2	87-A50-345-010	COIL, FM BPF D	A

ELECTRICAL MAIN PARTS LIST - 5/5


L	3	87-A50-350-010	COIL, BAR ANT AMN (COI)	A
L	10	87-005-849-080	COIL, 10UH (CECS)	A
Q	3	87-026-230-080	CHIP-TR,DTA114YK	A
Q.	2	89-327-125-080	CHIP TR, 2SC2712GR	A
Ō	1	89-327-143-080	TR,2SC2714 (0.1W)	A
Ŝ	1	87-A91-548-010	SW,SL-2-3 SK23E01G06	A
VC	1	87-A91-315-010	TUN-CAP,40P-140P D(TWD)	A


MECHANICAL PARTS LIST - 1/1


NOTE: The characters in the suffix column indicate the part usage.				
LHSC		.XX KANRI	A	
REF.NO	PARTS NO.	NO. DESCRIPTION	SUFFIX	
	87-B00-010-010 8A-CD9-005-010	BADGE, AIWA 30.5-5.2 S 2.5L CHAS, CD A	A A	
	8A-CD9-007-010	WINDOW, CD	A	
	8A-CD9-008-010 8A-CD9-009-010	BOX, CASS WINDOW, CASS	A	
	8A-CD9-011-010	HANDL, ARM	A	
	8A-CD9-012-010 8A-CD9-013-010	HANDL,GRIP PANEL,VOL	A A	
	8A-CD9-022-010	LENS, LED	A	
	8A-CD9-023-010 8A-CD9-024-010	POINTER, TU KEY, CASS TN21	A	
	8A-CD9-034-010	WINDOW, TU U	A	
	8A-CDK-001-010 8A-CDK-003-010	WINDOW, LED RC BOX, CD K-LH	A A	
	8Z-CDB-169-010	PANÉL, CD SANYO	A	
*	8A-CD9-004-010 8A-CD9-010-010	CABI,REAR B1 LID,BATT	A	
*	8A-CD9-062-010	CABI, FR B1 ASSY	A	
	8A-CD9-014-010 8A-CD9-017-010	BTN, VOL BTN, QSOUND	A	
	8A-CD9-018-010	CAP, CD A	A	
	8A-CD9-019-010 8A-CD9-020-010	CAP, CD B	A A	
	8A-CD9-021-010	BTN, REPEAT BTN, EQ	A	
	8A-CD9-026-010	KNOB, RTRY TU	A	
	8A-CD9-027-010 84-CD5-215-010	KNOB, SL BAND GEAR	A A	
	84-CD5-216-010	BRACKET	A	
	84-CD5-217-010 86-CT4-218-010	PLATE, MAGNET CUSHION, FOOT/PORON	A	
	87-036-368-010	MAGNET	A	
	87-CD6-213-010 8A-CD9-206-010	SPR-C,BATT (-) GEAR,TU A	A	
	8A-CD9-207-010	GEAR, TU B	A	
	8A-CD9-208-010 8A-CD9-209-010	DRUM,TU LEVER,BAND A	A A	
	8A-CD9-223-010	SPR-P, REC TN21	A	
	8A-CD9-231-010 8A-CD9-232-010	SPR-T,CD SPR-T,CASS	A A	
	8A-CH4-211-010	COVER, HLDR PT	A	
	8Z-CH4-211-010 8Z-CH4-212-010	BASE, CHUCK RING, CHUCK	A A	
JL.	8Z-CH4-225-010	HLDR, CHUCK A(S)	A	
*	8A-CD9-201-010 8A-CD9-202-010	HLDR, DISPLAY GUIDE, LED	A A	
*	8A-CD9-203-010	GUIDE, VOL	A	
*	8A-CD9-205-010 8A-CD9-211-010	GUIDE,GEAR HLDR,PWB L	A	
*	8A-CD9-212-010	HLDR, PWB R	A	
*	8A-CD9-221-010 8A-CD9-222-010	HLDR, ANT HLDR, SPEAKER	A	
*	8A-CH4-209-010	HLDR, PT	A	
	87-067-566-010 87-251-073-410	TAPPÍNG SCREW, VFTT+3-6 SCREW,U+2.6-6	A	
	87-255-096-410	U+3-10 NI	A	
	87-342-074-010 87-352-075-210	UT2+2.6-8 VT2+2.6-10	A	
	87-571-032-410 87-571-033-410	VIT+2-3	A	
	87-661-095-410	TAPPING SCREW, VIT+2-4 VFT1+3-8	A	
	87-661-097-410	TAPPING SCREW, VFT1+3-12	A	
	87-741-096-410 87-B10-239-010	UT2+3-10 QT2+3-8 W/O CR	A	
	87-B10-242-010	ŪT2+3-30 W/O CR	A	
	87-B10-269-010 87-WA5-253-010	UT2+3-12 W/O CR W,3.3-10-0.8	A	
*	87-751-094-410 87-035-347-010	VT2+3-6 W10SLOT FUSE,2.5A 250V T	A	
*	87-035-347-010	SW, PUSH LOCK	A A	
*	87-A60-178-010	JACK,AC E W/SW	A	
*	87-A91-369-010 8Z-CH4-640-010	SW,AC SL 2 2 SDKGA41700 ANT,ROD	A	
CNA 0	8A-CD9-626-010	CONN ASSY, 2P DOOR	A	
CNA 0 CNA 0	8A-CD9-630-010 8A-CD9-631-010	CONN ASSY,4P RPH CONN ASSY,4P TP-ME	A A	
CNA 0	8A-CD9-633-010	CONN ASSY, 4P SP	A	
FC 902 FC 901	87-033-213-010 87-033-213-010	CLAMP, FUSE SMK CLAMP, FUSE SMK	A	
PT 0	8A-CD9-604-010	PT,H 4.5WT04541A	A	
SP 0 W 0	88-CD5-602-010 8A-CD9-620-010	SPKR 4'3.2 FF-CABLE, 16P FR-MAIN	A	
M O	8A-CD9-621-010	FF-CABLE, 16P CD-RF	A	
W O	8A-CD9-622-010	FF-CABLE, 8P CD-FR	A	


ACCESSORIES / PACKAGE LIST - 1/1


NOTE: The	characters in	the suffix column	indicate the	part usage.
LHSC				A
REF.NO	PARTS NO.	KANRI NO. DESCRIPTION	ON	SUFFIX
	8A-CD9-902-010 87-A80-036-010 87-A90-312-010 8Z-CD5-634-010 8Z-CDK-962-010	PLUG, CONVERSION	T	A














アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 **2**03 (3827) 3111 (代表) **AIWA CO., LTD.** 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111 9820527